

This item is used to secure the Umbrella closed while it is inside the umbrella stand.



This rubber component is used to secure the Phone to the Charger. Simply stretch the rubber so that the corners of the phone are covered and within each corner of the rubber.



This item is connected to the small hook with the phone charger. It is used to help organize and secure the charging cable during use.



These items allow for alternative connection points for the remote holder box, or future accessories to connect to.

