



Grouping Mode Instructions

This guide is intended to outline how to enable and use grouping mode. This functionality is only compatible with CaddyTrek BAs, R2s, and Bigfoot units. CaddyTrek CT2000 units are not supported.

1. Gather the players in the group that will be golfing and that also have qualified CaddyTrek units.
2. While all handsets are in Standby (SB) mode and standing within five feet from each other, press the remote directional buttons in the following sequence: UP, DOWN, LEFT, RIGHT. Wait for all players to complete the sequence and then press STOP together.



3. If done correctly the handsets will flash the four lights in sequence indicating that the handsets are searching for the other players.

Problems Grouping

If one or more players did not do this correctly they will have ten seconds to try again while the successful handsets are still searching (the lights will still flash in sequence).

If some players become grouped (the SB light and the OA light will blink together at the same time on all handsets that have successfully grouped) the players who are grouped should re-enter the button sequence to break the group and try again.

4. Once successfully grouped, the SB light and the OA light will blink together at the same time on all handsets.



5. The group will not break until the button code is re-entered or if all of the units have been powered of for an extended period of time.